



Greens filter maintenance

Clean your air filter between 7000-10000 km (4500-6000 miles) or every 6 months. Clean more frequently if the vehicle is being operated in dusty conditions.

Cleaning Procedure

- Remove the filter
- Clean the filter with an air blower / airline to remove the largest impurities. Keep the blower at a distance of at least 15cm from the filter.
- Apply Greens filter cleaning solution to the filter
- Allow the product to work for around 15 minutes. If the filter is dirty then rub the surface with a clean paintbrush.
- Rinse the filter in hot water first on the inside, then on the outside.
- For deeply fouled filters, repeat the operation.
- Shake the filter to clear the bulk of the water.
- Dry the filter on a warm radiator or hair dryer on a low setting
- Spray Greens filter oil evenly across the surface of the filter.
- Refit the filter

Only use genuine Greens filter maintenance products. Greens filter maintenance products are available from Devon 4x4, quote reference numbers :

- NET.1 – Cleaner
- H300 – Filter Oil
- NH01 – Filter Cleaner + Oil Pack